

## AQUAPAC Fit Guide - Camcorders

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Aiptek   Canon   Hitachi   JVC   Mustek   Nisis   Panasonic  
 Samsung   Sharp   Sony

Make/Model	Camcorder Case
<b>Aiptek</b>	
Pocket DV3	Palm
<b>Canon</b>	
DC10/20/40/100	Barrel
DM XM2	Sorry, no fit
Elura2 (mc)	Palm
Elura40mc /65	Palm
GL1/2	Sorry, no fit
G45Hi	Sorry, no fit
MV20	Palm
MV300/350E	Barrel
MV30i	Barrel
MV3i	Palm
MV450i	Barrel
MV500i	Barrel
MV550i	Barrel
MV5i MC	Palm
MV600	Barrel
MV630i	Barrel
MV650	Barrel
MV650i	Barrel
MV700/700i/730i/750i	Barrel
MV880i	Barrel
MVX100i	Barrel
MVX10i	Palm
MVX150i	Barrel
MVX2i	Palm
MVX6i MC	Palm
MVX4i	Palm
MVXi	Palm
MVX250i	Palm
MCX351i	Sorry, no fit
Optura 100mc	Palm
Optura 400	Palm
V75Hi	Sorry, no fit
ZR20	Barrel
ZR25	Barrel
ZR30	Barrel
ZR40	Barrel
ZR45	Barrel
ZR50	Barrel

## AQUAPAC Fit Guide - Camcorders

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Aiptek   Canon   Hitachi   JVC   Mustek   Nisis   Panasonic  
 Samsung   Sharp   Sony

Make/Model	Camcorder Case
ZR65	Barrel
ZR70	Barrel
ZR85	Barrel
ZR100	Barrel
ZR200/300	Barrel
ZR500/600/700	Palm
<b>Hitachi</b>	
DZ MV 230E	Sorry, no fit
DZ MV 350	Barrel
DZ MV 380	Barrel
DZGX20A	Barrel
<b>JVC</b>	
GR D20/30/50/60/70/200(EK)	Barrel
GR D240	Palm
GR DF470	Barrel
GR DV400/4000(EK)	Barrel
GR DV700(EK)	Barrel
GR DVL109	Barrel
GR DVL140	Barrel
GR DVL167	Barrel
GR DVL367	Barrel
GR DX95EK	Barrel
GR X5	Barrel
GZ MC500/200	Barrel
GZ MG50	Barrel
GR-AX970	Sorry, no fit
GR-DMV96	Palm
GR-DV300	Palm
GR-DV3000E	Sorry, no fit
GR-DVM75	Palm
GR-DVM90	Palm
GR-DVP 8	Palm
GR-DVP 9	Palm
GR-DVP3	Palm
GR-DVP3U	Palm
GR-DVP7A	Palm
GR-DVX	Palm
GR-DVX48	Palm
GR-DVX507	Palm
GR-DVX707	Palm
GR-DVX78	Palm
GR-DVX9EG	Palm

## AQUAPAC Fit Guide - Camcorders

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Aiptek   Canon   Hitachi   JVC   Mustek   Nisis   Panasonic  
 Samsung   Sharp   Sony

Make/Model	Camcorder Case
GR-DX100	Palm
GR-DX25/35/45/55/75/95	Palm
GR-DX97U	Palm
GR-FX15EK	Sorry, no fit
GR-FXM39EK	Sorry, no fit
GR-PD 1	Sorry, no fit
GR-SX25EK	Sorry, no fit
GR-SXM29	Sorry, no fit
GR-SXM49EK	Sorry, no fit
<b>Mustek</b>	
DV3000	Palm
Mustek DV3032	Palm
DV2000	Barrel
<b>Nisis</b>	
Pocket DV4	Palm
Pocket DV2	Palm
<b>Panasonic</b>	
AG-DVC30	Sorry, no fit
AG DVX 100	Sorry, no fit
NV DS35B	Palm
NV DS55B	Palm
NV EX3B	Palm
NV GX7B	Palm
NV-DS 29	Barrel
NV-DS 65/60(B)	Barrel
NV-DS1	Barrel
NV-DS530	Barrel
NV-GS 1/3/4/10(B)	Barrel
NV-GS 30/40/50/70(B)	Barrel
NV-GS120	Barrel
PV-GS65	Barrel
PV-GS150/250/300/400	Barrel
NV-GS11	Palm
NV-MX5 EG/ MX500	Barrel
NV-VZ17B	Sorry, no fit
PV-DV 100	Sorry, no fit
PV-GS31/32/35	Barrel
PV-L354	Sorry, no fit
PV-VM202	Palm
SV AV10	Palm
SV AV20	Palm

## AQUAPAC Fit Guide - Camcorders

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Aiptek   Canon   Hitachi   JVC   Mustek   Nisis   Panasonic  
 Samsung   Sharp   Sony

Make/Model	Camcorder Case
SV AV20	Barrel
VDR M30/53/75	Barrel
FZ30	Sorry, no fit
<b>Samsung</b>	
SC-X105L	Palm
SCD107	Sorry, no fit
VP-D20	Barrel
VP-D21i	Barrel
VP-D26i	Barrel
VP-D31	Barrel
VP-D33i	Barrel
VP-D34 / 39	Barrel
VP-D340	Palm
VP-D380i	Palm
VP-D5000i	Sorry, no fit
VP-D530i	Palm
VP-D590i	Palm
VP-D80	Barrel
VP-D93	Barrel
VP-D97	Barrel
VP-L850	Sorry, no fit
<b>Sharp</b>	
VLPD6H	Barrel
VL-Z1H	Barrel
VL-Z3H	Barrel
VL-Z3S	Barrel
VL-Z5H	Barrel
VL-Z5S	Barrel
VL-Z7S	Barrel
<b>Sony</b>	
CCD TRV 608	Sorry, no fit
CCD TRV218	Sorry, no fit
DCP-PC-120E	Palm
DCR DVD 200/100	Barrel
DCR DVD 105/205/305	Barrel
DCR DVD 403	Barrel
DCR DVD 201E	Palm
DCR DVD 91E/92	Palm
DCR IP 220	Barrel
DCR IP 55	Barrel

## AQUAPAC Fit Guide - Camcorders

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Aiptek   Canon   Hitachi   JVC   Mustek   Nisis   Panasonic  
 Samsung   Sharp   Sony

Make/Model	Camcorder Case
DCR PC330	Sorry, no fit
DCR TRV 10E	Barrel
DCR TRV 14/33	Palm
DCR TRV 19/20	Barrel
DCR TRV 30E/33E	Barrel
DCR TRV355/ 480	Barrel
DCR TRV 530/27/320	Barrel
DCR TRV 60/80/17/18	Barrel
DCR TRV 110E/120E	Sorry, no fit
DCR TRV145	Sorry, no fit
DCR TRV22	Palm
DCR TRV240	Sorry, no fit
DCR TRV245	Sorry, no fit
DCR TRV250/260/270/280	Barrel
DCR TRV310	Sorry, no fit
DCR TRV 340/350	Sorry, no fit
DCR TRV 520	Sorry, no fit
DCR TRV 620E	Sorry, no fit
DCR TRV900/900E	Sorry, no fit
DCR TRV950	Sorry, no fit
DCR VX2000	Sorry, no fit
DCR VX2100E	Sorry, no fit
DCR-HC 16E/20/21	Palm
DCR-HC30 / 40/32E/42	Palm
DCR-HC96	Barrel
DCR-IP7/ IP1	Palm
DCR IP 55	Barrel
DCR IP 220	Barrel
DCR-PC 103/105	Palm
DCR-PC1/PC1/55	Palm
DCR-PC100/1000	Palm
DCR-PC-101E	Palm
DCR-PC110E	Palm
DCR-PC115	Palm
DCR PC 103	Palm
DCR-PC120E/PC120	Palm
DCR PC 330	Palm
DCR-PC3/PC3E/PC4/PC5/PC9/PC10	Palm
GR DVP 8/9	Palm
GR DX 35/55/25(EK)	Palm