

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Canon	
Digital IXUS 30/40/50/55/60/65/430/700/750	Compact
Digital IXUS 330/400/500	Sorry, no fit
Digital IXUS 800 IS	Compact
Digital IXUS i5/i/i zoom	Compact
Digital IXUS II/IIs	Compact
Digital IXUS v2/v3	Compact
Digital IXUS Wireless	Compact
EOS 3	Sorry, no fit
EOS 1D/1D Mark II N/1Ds/1Ds Mark II	Sorry, no fit
EOS 5/10/20/30D	Sorry, no fit
EOS 20Da	Sorry, no fit
EOS 3000N	SLR
EOS 1V	Sorry, no fit
EOS 33V	Sorry, no fit
EOS 30V Date	Sorry, no fit
EOS 300V/3000V	SLR
EOS 300/300X/350D/350D Rebel XT	SLR
Powershot A30/60/70/75/80/85/95	Compact
Powershot A300/310/400/410/420/430	Compact
Powershot A510/520/530/540	Compact
Powershot A610/620/700	Compact
Powershot G1/2/3/6	Large
Powershot G5	SLR or Large
Powershot Pro 1	Sorry, no fit
Powershot S1/S2 IS	SLR or Large
Powershot S3 IS	Sorry, no fit
Powershot S45/50/60/70/80	Compact
Powershot SD400/430/450	Compact
Prima Super 90uII/115uII/130u/150u/180 Date	Compact
Casio	
Exilim Card EX - S100/600	Compact
Exilim Pro EX - P600/700	Compact
Exilim Pro EX - P505	Large
Exilim Zoom EX - 750	Compact
Exilim Zoom EX - S500	Compact
Exilim Zoom EX - Z110/120	Compact
Exilim Zoom EX - Z30/40/55/57/60	Compact
Exilim Zoom EX - Z500/600/750/850/1000	Compact
QV R41/51/61	Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Contax	
Aria	SLR
G1/2 Rangefinder	Large
N1 Auto Focus	Sorry, no fit
NX Auto Focus	Sorry, no fit
RTS III	Sorry, no fit
RX II	Sorry, no fit
T Series T3	Compact
T Series Tix	Compact
T Series TVS III (No JPG image available)	Sorry, no fit
U4R/I4R	Compact
Epson	
P-2000/4000	Compact
RD1	Compact
Fuji	
@xia SlimShot	Compact
FinePix A120	Compact
FinePix A330/340/345/350/360 Zoom	Compact
FinePix A370	Compact
FinePix A400/405/410 Zoom	Compact
FinePix A403	Compact
FinePix A500 Zoom	Compact
FinePix A605	Compact
FinePix A607 Zoom	Compact
FinePix E500/510/550/900 Zoom	Compact
FinePix F10/11/30 Zoom	Compact
FinePix F420/440/450/455/460/470 Zoom	Compact
FinePix F610/710/810 Zoom	Compact
FinePix S1/2/3 Pro	Sorry, no fit
FinePix S20 Pro Zoom	Sorry, no fit
FinePix S3100/5100/5600/7000/9500	Sorry, no fit
FinePix V10	Compact
FinePix Z1/2 Zoom	Compact
HP	
Photosmart E317/327	Compact
Photosmart M22	Compact
Photosmart M417/517	Compact
Photosmart M525/527	Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Photosmart R717/727/817/818/927	Compact
Photosmart 945	Large
Kodak	
DC200/210	Large
DC200/210 Plus	Large
DC215/220/240/260/265/280/290	Large
DC3400/3800	Compact
DC3200/4800/5000	Large
DCS315/330/420/460/520/560/620/660/760	Sorry, no fit
DCS620/720x	Sorry, no fit
DX-3700	Sorry, no fit
Easyshare C300/310/315/330/360	Compact
Easyshare C340	Large
Easyshare C503/530/533/603/643/663	Compact
Easyshare CD33/40/43	Compact
Easyshare CW330	Compact
Easyshare CX4310	Compact
Easyshare CX6230/6300/6330/6445	Compact
Easyshare CX7220/7300/7310/7330	Compact
Easyshare CX7430/7525/7530	Compact
Easyshare DX3215/3500/3600/3700/3900	Compact
Easyshare DX4330/4530/7630	Compact
Easyshare DX6340/6440/7440	Compact
Easyshare DX6490/7590	Large
Easyshare LS633/743/753/755	Compact
Easyshare P850	Large
Easyshare P880	Sorry, no fit
Easyshare V530/550/603	Compact
Easyshare V570/610 Dual Lens	Compact
Easyshare Z612/650	Large
Easyshare Z700/730/740/760	Large
Easyshare Z7590	Large
Konica	
KD 100	Compact
KD 220Z	Compact
KD 310Z	Compact
KD 400Z	Compact
KD 500Z/500G	Compact
KD 510Z	Compact
Revio C2	Compact
Minolta Maxxum 5D	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Minolta A200	Sorry, no fit
Kyocera	
Finecam L3/L3v/L4/L4v/S3L/S3X/S4/S5/S5R	Compact
Lecia	
M7	Large
MP	Large
R8/9	Sorry, no fit
CM/CM Zoom	Compact
Minolta	
Dimage 5	Sorry, no fit
Dimage 7/7i/ 7hi	Sorry, no fit
Dimage A1 / A2	Sorry, no fit
Dimage E223	Compact
Dimage E323	Compact
Dimage F200	Compact
Dimage F300	Compact
Dimage S414	Compact
Dimage xt / xi / x / x20 / x50 / x60	Compact
Dimage Z1, Z2/3/10/20	Large
Dynax 303	Sorry, no fit
Dynax 3L	SLR
Dynax 4	SLR
Dynax 404	Sorry, no fit
Dynax 5	SLR
Dynax 7	Sorry, no fit
Dynax 9	Sorry, no fit
Maxxum 3 QD / 4 QD / 5 QD	SLR
Maxxum 500si	Sorry, no fit
Maxxum 7	SLR
Maxxum 7D/700si	Sorry, no fit
Maxxum 8000i	Sorry, no fit
Maxxum 800si	Sorry, no fit
Maxxum 9	Sorry, no fit
Maxxum HTsi	SLR
Maxxum QTsi	SLR
Maxxum STsi (QD)	SLR
Maxxum XTsi	SLR
RD3000	Sorry, no fit
Riva 140mm	Compact
Vectis S-1	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Vectis S-100	SLR
X-370	Large
Nikon	
AF220/230/240/250	Compact
Coolpix L1	Compact
Coolpix P1	Compact
Coolpix 3100/3200/2100/2000	Compact
Coolpix 3700/4300/4600/4100/2500	Compact
Coolpix 5200	Compact
Coolpix 5400/SQ/4500/4800	Large
Coolpix 7900/775	Compact
Coolpix 3500	Compact
Coolpix 5700/8700/8800	Sorry, no fit
Coolpix 880/885/990/995	Large
Coolpix 775	Compact
D100/D200	Sorry, no fit
D1X/D2X	Sorry, no fit
D2H	
D50	SLR
D70	SLR
F100	Sorry, no fit
F3HP	Sorry, no fit
F4s	Sorry, no fit
F5/F6	Sorry, no fit
F65/ 55/55D	SLR
F80D	SLR
F90x	Sorry, no fit
FM10	SLR
FM2N	Sorry, no fit
FM3A	SLR
LiteTouch " 110/130/150	Compact
LiteTouch Zoom 70w/100w	Compact
N55	SLR
N60	SLR
N65	SLR
N70	SLR
N75	SLR
N80	SLR
N8008s	Large
N90s	SLR
Nuvis Mini1/75i/125i	Compact
OneTouch Zoom 90/90s	Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Pronea 600i/6i	SLR
Pronea S	SLR
Zoom 3120AF	Compact
Olympus	
700BF/800	Compact
Accura 80	Compact
C - 1/21/100/220Z/720Z	Compact
C - 1Z/4/8/9/50/51/ 60/300	Compact
C - 200Z/350Z/860L/990Z	Compact
C - 700UZ/720UZ/730UZ	Large
C - 740/960/970	Large
C - 765 Ultra Zoom	Large
C - 7000	Compact
C- 150/350/500/505	Compact
C- 2000Z/2020Z/2040Z/3000	Large
C- 3020Z/3030Z/3040Z/4040/990Z	Large
C- 4000/5050/5060	Large
C- 4040Zoom	Large
C- 740/750/760/765/770/730UZ	Large
C700/C2100UZ	Sorry, no fit
C2500L	Sorry, no fit
C5050Z	Large
C-8080 Wide Zoom	Sorry, no fit
Camedia C-40/50Zoom	Compact
D- 560/390/510/550/630	Compact
D-500L/600L/620L	Sorry, no fit
E-1/10/20	Sorry, no fit
E-100RS/	Sorry, no fit
IS-20 (QD)	Sorry, no fit
IS-30	Sorry, no fit
IS-5	Sorry, no fit
IS-50	Sorry, no fit
Evolt E-300	SLR
LT Zoom 105/120	Compact
MJU - 1/II	Compact
MJU 300	Compact
MJU 400	Compact
MJU III Zoom 115/120	Compact
MJU Zoom 115/80/140	Compact
Newpic 60	Compact
OM-2	SLR
OZ10	Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Stylus 35mm	Compact
Stylus Verve	Compact
Stylus Zoom 140/400/ 300	Large
Superzoom 700BF / 800	Compact
Superzoom 80W/105/120	Compact
Zoom 2000	Large
Zoom 310	Compact
Panasonic	
DMC F1/F7	Compact
DMC FZ 1/FZ3/FZ5	Large
DMC FZ4S/FZ5S	SLR
DMC FZ /10/15/20	Sorry, no fit
DMC LZ1/LZ2/LZ2K	Compact
DMC LC20	Compact
DMC LC40	Large
DMC LC43/33/80	Compact
DMC LC5	Large
DMC LX1	Compact
DMC FX7	Compact
Pentax	
EI - 100	Compact
EI - 200	Compact
EI-2000	Sorry, no fit
ESPIO 110Zoom/120/140/160	Large
ESPIO 115M Zoom	Compact
ESPIO 90MC/ 738G/838/928	Large
Optio WP	Compact
Optio S /S4	Compact
Optio S/330/550/450/33L/330	Compact
Optio S5i /S5Z	Compact
115M	Compact
160/738G/838/928	Large
Istd	SLR
MZ-S (QD)	SLR
645N	Sorry, no fit
Pro90 IS	Sorry, no fit
Pz-1p	Sorry, no fit
ZX 30	SLR
ZX 5n	SLR
ZX 60	SLR
ZX L	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
ZX M	SLR
Ricoh	
Caplio G3 /G4	Compact
Caplio RR 30/230	Compact
Caplio RR1 /RDC-7	Compact
RDC-5300	Compact
GR - 21	Large
Samsung	
Digimax 101	Compact
Digimax 201/301	Compact
Digimax 230/ 350	Compact
Digimax 240	Compact
Digimax 50 Duo/130/200/V4	Compact
Digimax 370	Large
Digimax 330	Large
SDC - 200ZNexca	Large
SR4000	SLR
Sanyo	
DSC-J1	Compact
Sigma	
SA7N	SLR
SA9	Sorry, no fit
SD9	SLR
SD9/10	Sorry, no fit
Sony	
DSC-F77/77X/88	Compact
DSC-F707/717/828	Sorry, no fit
DSC-H1/2	Sorry, no fit
DSC-L1/N1	Compact
DSC-P1-10/12/32/41/43/52//72/73/92/93/93A	Compact
DSC-P100/150/200	Compact
DSC-R1	Sorry, no fit
DSC-S40/60/80/90	Compact
DSC-S85	Sorry, no fit
DSC-T1/3/5/5N/7/9/33	Compact
DSC-U20/30/40	Compact
DSC-V1	Compact
DSC-V3	Large

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax PicoH Samsung Sanyo Sigma Sony

Make/Model	Camera Case
DSC-W1/5/7/30/50/70/100	Compact